






Product:Electric Planer Art.No. 568204S

No.	Part Name(Chinese)	Part Name(English)	Code	Qty	No.	Part Name(Chinese)	Part Name(English)	Code	Qty
1	商标	Trademark	20401001253	1	47	电缆压板	Cord Anchor	10101011123	1
2	螺钉M4×12	Screw M4×12	30201008	8	48	小护套	Small Sleeve	10102001022	1
3	皮带罩	Belt Cover	10101011110	1	49	电源线3×0.75	Cord	10602006090	1
4	皮带	Belt	10101011113	1	50	螺钉M4×8	Screw M4×8	30201048	1
5	小皮带轮	Small Pulley	10302010015	1	51	出风罩	Air Outlet Hood	10101005119	1
6	螺钉M4×25	Screw M4×25	30201027	5	52	铭牌	Nameplate	20302001992	1
7	侧盖	Side Cover	10204004150	1	53	轴承压盖	Bearing Cover	10401002038	1
8	轴承6200-2RS	Bearing 6200-2RS	30103067	2	54	后罩	Rare Cover	10101003077	1
9	大皮带轮	Big Pulley	10302010014	1	55	螺钉M4×12	Screw M4×12	30201010	2
10	转子	Armature	10502001190	1	56	螺钉M5×14	Screw M5×14	30201061	2
11	轴承608-2RZ	Bearing 608-2RZ	30103056	1	57	装刀架	Blade Adjust Block	21201005007	1
13	挡风圈	Air Deflector	10101005121	1	58	螺钉ST6×12	Screw ST6×12	30202102	4
14	螺钉M4×60	Screw M4×60	30201124	2	59	磨刀架	Blade Sharpening Rack	21201005010	1
15	定子	Stator	10501001175	1	60	导尺	Guide Ruler	21201003026	1
16	拉簧	Spring Rig	10607001019	2	61	套筒扳手	Socket Wrench	21201002035	1
17	机壳	Housing	10202004082	1	65	刀轴组件(26~30)	Cutter Shaft Assembly	10701003007	1
18	扭簧	Torsion Spring	10303001107	1					
19	尾脚	Tail Foot	10101011124	1					
20	后底板	Rear Base Plate	10207004050	1					
21	绝缘垫圈	Insulating Washer	10401007003	2					
22	刷握	Brush Holder	10606001075	2					
23	碳刷	Carbon Brush	10605001104	2					
24	刷握盖	Brush Cap	10606001076	2					
26	刀轴	Cutter Shaft	10301009019	1					
27	刀片	Blade	21201006023	2					
28	刀轴压盖	Cutter Shaft Gland	10204004152	2					
29	带平弹垫螺钉M4×10	Screw M4×10	30201004	4					
30	六角法兰面螺栓M6×18	Screw M6×18	30208002	6					
31	轴承6000-2RS	Bearing 6000-2RS	30103005	1					
32	平头销3×9.8	Pin 3×9.8	30701041	1					
33	塑料螺钉	Plastic Screw	30206022	1					
34	前底板	Front Base Plate	10207004046	1					
35	海绵垫	Sponge Pad	10401006024	1					
36	弹簧	Spring	10303001106	1					
37	旋钮	Knob	10101007147	1					
38	旋钮盖	Knob Cover	10101008052	1					
39	手轮标	Handwheel Mark	21001001139	1					
40	螺钉ST4×25	Screw ST4×25	30202034	2					
41	螺钉ST4×14	Screw ST4×14	30202019	4					
42	左手柄	Left Handle	10101004316	1					
44	开关	Switch	10601001187	1					
45	右手柄	Right Handle	10101004310	1					
Version No.		D			Enable Time		2022.8		