




No.	Part Name(Chinese)	Part Name(English)	Code	Qty	No.	Part Name(Chinese)	Part Name(English)	Code	Qty
1	螺盖	Screw Cover	10801013060	1	45	悬吊组件 由19-23\P零件组成	Suspension Assembly (consisting accessories of 19~23\ P)	10801013102	1
2	支腿	Outrigger	10801013061	3					
3	底座	Base Bracket	10801013062	1					
4	微调组件	Trim Assembly	10801013063	1	46	手轮组件 由35-44\ P零件组成	Hand Wheel Assembly (consisting accessories of 35~44\ P)	10801013103	1
5	动圈	Moving Circle	10801013064	1					
6	对地玻璃	Ground Glass	10801013065	1	47	外壳组件 由24-34\ P零件组成	Housing Assembly (consisting Accessories of 24~34\ P)	10801013104	1
7	压板	Anchor	10801013066	3					
8	转盘	Turntable	10801013067	1					
9	主板	Main Plate	10801013052	1					
10	接线板	Terminal Block	10801013068	1					
11	立柱	Upright Column	10801013069	3					
12	导电O型圈	Conductive O Ring	10801013070	1					
13	一体化重锤	Integrated Hammer	10801013071	1					
14	对地激光器	Ground Laser	10801013072	1					
15	O型圈	O Ring	10801013073	1					
16	配重块	Clump Weight	10801013074	1					
17	摆体	Pendulum	10801013075	1					
18	激光器	Laser	10801013076	3					
19	长轴、螺纹套	Threaded Sleeve for Long Shaft	10801013077	1					
20	短轴、螺纹套	Threaded Sleeve for Short Shaft	10801013078	1					
21	螺钉M3×14	Set Screw M3×14	30201181	3					
22	上吊耳	Upper Lifting Lug	10801013079	1					
23	轴承、中间架	Middle Frame for Bearing	10801013080	1					
24	皮带	Belt	10801013081	1					
25	皮带扣	Belt Buckle	10801013082	2					
26	外壳	Housing	10801013083	1					
27	水泡	Blister	10801013084	1					
28	按键板组件	Key Plate Assembly	10801013085	1					
29	按键贴	Key Sticker	10801013086	1					
30	垂直窗口贴	Vertical Window Paste	10801013087	4					
31	水平玻璃	Horizontal Glass	10801013088	1					
32	水平窗框	Horizontal Window Frame	10801013089	1					
33	电池盒	Battery Box	10801013090	1					
34	电池盒盖	Battery Box Cover	10801013091	1					
35	锁紧板	Lock Plate	10801013092	1					
36	扭簧	Torsion Spring	10801013093	1					
37	扭簧衬套	Torsion Spring Sleeve	10801013094	1					
38	定位簧片	Location Spring	10801013095	1					
39	凸轮	Cam	10801013096	1					
40	微动开关	Microswitch	10801013097	1					
41	锁紧支架	Lock Supporter	10801013098	1					
42	开关盖	Switch Cover	10801013099	1					
43	插片	Illustration	10801013100	1					
44	手轮	Hand Wheel	10801013101	1					
Version No.		D			Enable Time			2022.8	