






Product:Cordless Impact Wrench

Art.No. D512001

No.	Part Name(Chinese)	Part Name(English)	Code	Qty	No.	Part Name(Chinese)	Part Name(English)	Code	Qty
1	带平弹垫螺钉M4×8	Screw M4×8	30201048	1					
2	透明罩	Transparent cover	10101011157	1					
3	自攻螺钉ST4.2×22	Screw ST4.2×22	30202098	4					
4	平垫圈（黑镍）	Flat Washer	30403047	4					
5	头壳	Gear Box	10201004245	1					
6	O型圈18×2.5	O ring 18×2.5	10102003133	1					
7	轴套	Spindle Sleeve	10306002132	1					
8	减震圈	shock absorption ring	10102004106	1					
9	冲击垫片30×18.1×1.5	Impact Gasket 30×18.1×1.5	30403129	1					
10	输出轴组件	Output Spindle Assembly	10701015029	1					
11	冲击头组件	Impact Set Assembly	10701015028	1					
12	行星齿轮	Planet Gear	10302004160	3					
13	行星齿轮销4×9.8	Planet Gear pin	30701104	3					
14	平垫片23×16.5×0.5	Washer 23×16.5×0.5	30403130	1					
15	轴承6902-2RS	Bearing 629	30103147	1					
16	孔用钢丝挡圈43	Circlip for Hole 43	30304006	1					
17	内齿轮	Internal Gear	10302004162	1					
18	中间盖	Middle Cover	10204004183	1					
19	定子（18V）	Stator	10501001317	1					
20	电机齿轮	Motor gear	10302004161	1					
21	转子组件（18V）	Armature Assembly	10701014031	1					
22	换向推杆	Switch Reversal Rod	10101007188	1					
23	铭牌	Name plate	20302001821	1					
24	自攻螺钉ST3×14	Screw ST3×14	30202097	9					
25	右机壳	Right Housing	10101002126	1					
26	左机壳	Left Housing	10101002125	1					
27	无刷标贴	Brushless label	21002001588	1					
28	开关	Switch	10601001212	1					
29	功能标贴	Function label	21002001589	1					
30	功能板	Function board	101011156	1					
31	控制器	controller	10608002058	1					
32	接插板	Patch panel	10101011151	1					
33	LD1840电池包	Battery LD1840	56101064	1					
34	接插板复位弹簧	Spring	10303001129	1					
35	六角螺母M4	Hex nuts M4	30501056	1					
36	皮带扣	Belt Clip	21201010055	1					
37	挂绳	Hanging rope	21201010053	1					
38	CD1822充电器	Changer CD1822	10608001039	1					
39	套筒	Sleeve	10401008043	1					
40	腰带	belt	21201010054	1					
41	带平弹垫螺钉M4×10	Screw M4×10	30201004	1					
42	弹簧套	Spring sleeve	10303001141	1					
43	平头销	pin	30701105	1					
44	套筒组件	Sleeve Assembly	10701015030	1					
Version No.		D			Enable Time		2022.8		